


shot tee

instructions for use

For unpaved beds and greens

1. Loosen firm soil first.
2. Stick ground spike in the ground in intended position without applying pressure to the bowl (according to sketch).
3. Place luminaire shot in the bowl.
The ball should be tilted only that far, that backwater can't ingress directly into cable- and mebrane tunnel – see figures.



care:

Regularly clean shot tee and luminaire from dirt and deposits.
Do not use a high pressure cleaner for cleaning.
Please note care instructions at www.IP44.de.

